

## Operating Instructions

### Daily Plug-In Mechanical Timer

Part No.: MPIT3C

#### 1. Setting the On/Off periods

##### Daily plug-in Timer:


This timer can be used to set up to 48 On/Off periods a day.

Using your finger, a pen or screw driver pull up all the segments that correspond to the required “Off” period. For the required “On” period make sure the segments are pushed down.

Each segment represents 15 minutes: 4 segments=1 hour

#### 2. Setting the time:

##### Daily Plug-in Timer:


Turn the dial clockwise ( as per indicating arrows ) until the arrow-located at the top right of the centre dial, is pointing to the correct time. Ensure that the manual override switch on the top of the unit is set to the  position.

#### 3. Connection

Once the required On/Off periods and time have been set, plug the Timer into the wall socket, and then the appliance plug into the Timer. Ensure that you then turn the wall socket and the appliance on.

The Timer will now start to operate and switch on and off according to where the segments are in the up and down position.

#### 4. Manual On/Off

The pre-set On/Off commands can be interrupted by using the manual **I** -  switch (located on the top of the unit). By switching this to the **I** position the connected appliance will be switched on permanently without affecting the pre-programmed settings.

#### 5. Specification

power Supply:	AC240V, 50Hz
Capacity:	13A resistive load
Min. Temperature:	0°C
Max. Temperature:	55°C

#### 6. Precautions

For indoor use only.

Do not plug in any appliance which exceeds the capacity of the Timer. Always ensure that the plug of any appliance is fully inserted into the Timer.

If you need to clean the Timer, remove from the mains and wipe with a dry cloth. Do not immerse in water or any liquid.

Fan heaters and heaters with exposed elements should not be left unattended, and it is recommended that these types of appliances are not connected to timers.

#### 7. Accuracy of Timer

Daily Plug-In Mechanical Timer :  $\pm 5$  min